

Chapter 3.

RoboPhilo PS2 Operation

3.2 PS2 software tab

PS2 Tab 1. Routine assignment for selected mode of operation

Routine Name
 - Select the Routine for the corresponding PS2 controller button pressed

Select
 - Mark Routine assignments for deletion or Play

Mode init routine
 - the current High, mid, low routine will be run when the mode button is pressed.

High mode
 = L1, L1+R1 or R1 is pressed.

Mid mode
 = L1+L2, L1+L2+R1+R2 or R1+R2 is pressed

Low mode
 = L2, L2+R2 or R2 is pressed

The pictures show the current mode and how the opponent is facing your robot.

LEFT = opponent's left side is facing your robot.

CENTER = opponent's face is facing your robot.

RIGHT = opponent's right side is facing your robot.

